

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-7 Product Support Manuals (PSM)

| DHC-7 DASH 7 | | | | | |
|----------------|---|----------------|----------------------------|--|----------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-71-1 | Aircraft Operating Data | 10 | Nov. 10/05 | | 1 |
| 1-71A-1A-DOT | Airplane Flight Manual | 51 | June 02/05 | TA 10, TA 11 | 1 |
| 1-71A-1A-UK | Airplane Flight Manual (Series 110/111) | 20 | Aug. 12/05 | TA 2 | 1 |
| 1-7-2 | Maintenance Manual | 43 | Apr. 11/08 | 1, 5-104 to 5-118, 20-10 to 20-12, 24-1, 27-39, 28-1 to 28-4, 57-1, 57-2 | 8 |
| 1-7-2-VOL1 | Maintenance Type Board Controlled Program Chapter 5. Supersedes MRB. | Re-issued | Apr. 2008 | | 1 |
| 1-7-2-CCV | Maintenance Manual (Customized Chapters Volume 5 – Serial No. required) | 37 | Jan. 10/06 | | 1 |
| 1-7-2ER | Engine Rigging Manual | 3 | Dec. 20/02 | | 1 |
| 1-7-2S | Ramp Servicing Manual | 4 | Oct. 09/89 | | 1 |
| 1-7-2T | Tools and Equipment Manual | 6 | Feb. 28/85 | | 1 |
| 1-7-2TS | Trouble Shooting Manual | 4 | Dec. 20/02 | | 1 |
| 1-7-2W | Wiring Manual | 10 | May 27/05 | 28-1, 28-2, 30-1 | 2 |
| 1-7-2W-CCV | Wiring Diagrams Manual (Customized Chapters - Serial No. required) | 9 | Oct. 31/02 | 34-1, 34-2 | 1 |
| 1-7(28)-2W | Wiring Manual | 10 | Sep. 27/05 | 28-1 to 28-3, 30-1 | 2 |
| 1-7(28)-2W-CCV | Wiring Manual (Customized Chapters - Serial No. required) | 8A | May 31/93 | | 1 |
| 1-7-3 | Structural Repair Manual | 8 | Apr. 5/07 | 51-3 | 1 |
| 1-7-3RS | Structural Repair Schemes Manual | 5 | Jan. 24/05 | | 2 |
| 1-7-4 | Illustrated Parts Catalogue | 17 | July 31/14 | 30-1 | 6 |
| 1-7-5 | Corrosion Prevention & Control Manual | 1 (Erratum) | Nov. 30/02 (Oct. 31/03) | 4 to 10 | 1 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-7 DASH 7 | | | | | |
|---------------------|--|-----------------|----------------------------|---|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-7-6 | Component Maintenance Manual (Sold as is – no longer revised) | 16 | Jan. 31/03 | | 15 |
| 1-7-6A | Component Repair & Overhaul Manual (Sold as is – no longer revised) | 3 | Feb. 03/88 | | 1 |
| 1-7-7 | "D" Check Maintenance Manual | 1 | Dec. 20/02 | | 1 |
| 1-7-7A | Non-Destructive Testing Manual | 5 | July 05/05 | | 1 |
| 1-7-7E | Equalized Maintenance Manual | 11 | Nov. 08/13 | | 1 |
| 1-7-8 | Weight & Balance Manual (Series 100) | Revised | Apr. 1978 | | 1 |
| 1-71-8 | Weight & Balance Manual – Series 102 (Prepared for each aircraft on delivery) | 2 | Feb. 1982 | | 1 |
| 1-71C-8 | Weight and Balance Manual – Series 103 (Prepared for each aircraft on delivery) | 1 | Feb. 1979 | | 1 |
| 1-7-8A | Cargo Loading Manual | 2 | Apr. 30/82 | | 1 |
| 1-7-10 | Power Plant Build-Up Manual | 4 (Erratum) | Dec. 20/02 (Nov. 16/05) | | 1 |
| 1-7-12 | Modifications & Options Manual | 8 | July 01/00 | | 1 |
| 1-7-14 | Crash-Fire-Rescue Information Booklet (Sold as is – no longer revised) | Re-issued | Oct. 1989 | | 1 |
| 1-7-15 | Vendors Warranties Manual (Sold as is – no longer revised) | 5 | Sep. 10/85 | | 1 |
| 1-715-1A | Airplane Flight Manual (Series 150 (I.R.)) | 18 | June 02/05 | TA 1 | 1 |
| 1-715-2 | Maintenance Manual (Series 150 (I.R.)) (Vol. 1 to 4 & 4A) | 7 | Nov.08/13 | | 5 |
| 1-715-2 | Maintenance Type Board (MTB) Volume 1 - Chapter 5 | IR | Nov. 08/13 | 5-54 to 5-56, 5-63, 5-64A, 5-65 to 5-70 | 1 |
| 1-715-2-CCV | Maintenance Manual - Volume 5 - (Series 150 (I.R.)) | 1 | Jan. 15/90 | 24-1 | 1 |
| 1-715-2W | Wiring Diagrams Manual (Series 150 (I.R.)) | 3 | Feb. 14/90 | 26-1, 27-1, 28-1 to 28-3, 30-1, 32-2 | 2 |
| 1-715-2W-CCV | Wiring Diagrams Manual - Volume 3 - (Series 150 (I.R.)) | 14 | Feb. 14/90 | | 1 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | **Fax:** 403.295.8888 | **Email:** csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-7 DASH 7 | | | | | |
|---------------------|---|-----------------|----------------------|--|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-715-4 | Illustrated Parts Catalogue Supplemental (Series 150 (I.R.) SN102) (*to be sold with 1-7-4) | 12 | Apr. 01/86 | | 1 |
| 1-7-MMEL-DOT | Master Minimum Equipment List | 7 | May 11/98 | 4 to 12, 15 | 1 |
| 1-7-MMEL-FAA | Master Minimum Equipment List (FAA) Distributed by FAA | 14A | June 17/99 | | 1 |
| 1-7-MELP-DOT | Minimum Equipment List Procedures (DOT) | 8 | Aug. 30/04 | 16 | 1 |
| 1-7-MELP-FAA | Minimum Equipment List Procedures (FAA) Distributed by FAA | 5 | Jan. 31/03 | 10 | 1 |
| 1-GEN-5 | Corrosion Prevention and Control Manual (DHC-6, DHC-7 Dash 7, DHC-8 Dash 8) | 3 | Nov. 30/98 | | 1 |
| 1-7-SB | Service Bulletins (Index) | 9 | Mar.02/22 | | 5 |
| 1-7-SL | Service Letters (Index) | Index | Apr. 12/04 | | 1 |
| 1-7-TOLS | Take-Off and Landing Speeds | | | | 1 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-6 Product Support Manuals (PSM)

| DHC-6 TWIN OTTER (Common to Series 100, 200, 300, 400) | | | | | |
|--|--|--|---------------|--|----------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-6-2T | Ground Support Manual | 14 | May 21/19 | | 1 |
| 1-6-3 | Structural Repair Manual | 10 | May 18/18 | 53-5, 53-6 | 1 |
| 1-6-3RS | Structural Repair Schemes Manual | 10 | Jan. 18/22 | | 1 |
| 1-6-5 | Corrosion Prevention & Control Manual | 5 | Nov. 30/10 | 2-3 to 2-6, 2-7 to 2-8, 3-5 to 3-6 | 1 |
| 1-6-6A | Component Maintenance Manual (Series 100, 200 & 300) (Sold as is - no longer revised) | 12 | Dec. 18/01 | 23-1 to 23-3, 27-2, 27-3, 27-5, 28-1, 29-1, 29-2, 32-22 | 7 |
| 1-6-7 | Inspection Requirements Manual | 20 | Nov. 30/18 | 142, 147, 162, 217, 223, 227, 229 to 233, 236 to 243, 244 ¹ to 247 ² | 1 |
| 1-6-7-E | EMMA Package Complete (Incl. PSM1-6-7-D1 & PSM1-6-7-IC) | Refer to individual publications for revision level and date | | | 1 + 5 posters |
| 1-6-7-IC | EMMA Inspection Work Cards | 20 | Nov. 30/18 | 158, 223, 225 to 227, 230, 232 to 240, 241 ³ , 242 ⁴ , 243 | 1 |
| 1-6-11 | Airframe Airworthiness Limitations Manual | 9 | Apr. 30/18 | 1 | 1 |
| 1-6-12 | Modifications & Options Manual | 27 | Mar. 02/22 | | 1 |
| 1-GEN-5 | Corrosion Prevention and Control Manual (DHC-6, DHC-7 Dash 7, DHC-8 Dash 8) | 3 | Nov. 30/98 | | 1 |
| 1-6-SB/TAB | Service & Technical Advisory Bulletins | 18 | Mar. 02/22 | | 4 |
| 1-6-EPC | Emergency Procedure Cards (Series 300 & 400) – English Only (minimum quantity 50) | | | | 50 cards |
| 1-6-EPC/B | Emergency Procedure Cards (Series 100 & 200) – Bilingual Only (minimum quantity 50) | | | | 50 cards |

¹ TR 244 supersedes TR 240

² TR 247 supersedes TR 227

³ TR 241 supersedes TR 230

⁴ TR 242 supersedes TR 225

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-6 TWIN OTTER (Series 100) | | | | | |
|-------------------------------|--|---------------|---------------|---|----------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-6-1 | Operating Data Manual (Series 100 & 200) (*price includes 1-61-1A or 1-61-1A-ARB (Flight Manual)) | 1 | Sep. 28/90 | 1 to 5, 7 to 12 | 1 |
| 1-61-1A | Airplane Flight Manual (Series 1 & 100) (*price includes 1-6-1 (Operating Data Manual)) | 40 | Oct. 31/17 | TA 1 to 6 | 1 |
| 1-61-1A-ARB | Airplane Flight Manual (Series 110) (*price includes 1-6-1 (Operating Data Manual)) | 37 | Aug.10/05 | TA 1 to 5 | 1 |
| 1-6-2 | Maintenance Manual (Series 1, 100 & 200) | 7 | Sep. 28/18 | 158, 161,162, 164 to 166, 168 to 179, 180 to 182 | 1 |
| 1-6-2W1 | Wiring Manual | 2 | Nov. 24/05 | W2 to W10 | 1 |
| 1-6-4 | Illustrated Parts Catalogue (Series 100 & 200) | 4 | June 22/05 | 8 to 10, 14 to 20, 21 ⁵ , 22 ⁶ , 23 to 27 | 2 |
| 1-6-8 | Weight & Balance Handbook (Prepared for each aircraft on delivery) | Issue 6 | June 1968 | | 1 |
| 1-6-10 | Vendors Warranties Manual (Series 100, 200 & 300) | Initial Issue | N/A | | 1 |
| 1-6-7-D1 | Area Diagram (D1) including: | | | | 5 Posters |
| | 1-6-7(D2) – Access and Inspection Diagram | | | | |
| | 1-6-7(D3) – Lubrication Diagram (Updated May 2/14) | | | | |
| | 1-6-7(D4) – Servicing Diagram | | | | |
| | 1-6-7(D5) – Torque Values Diagram | | | | |
| | | | Jan. 31/06 | | |

⁵ TR-21 supersedes TR-16.

⁶ TR-22 supersedes TR-17.

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-6 TWIN OTTER (Series 200) | | | | | |
|--------------------------------------|--|-----------------|----------------------|---|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-6-1 | Operating Data Manual (Series 100 & 200) (*price includes 1-61-1A or 1-61-1A-ARB (Flight Manual)) | 1 | Sep. 28/90 | 1 to 5, 7 to 12 | 1 |
| 1-62-1A | Airplane Flight Manual (*price includes 1-6-1 (Operating Data Manual)) | 39 | Oct. 31/17 | TA 1 to 6 | 1 |
| 1-62-1A-ARB | Airplane Flight Manual (Series 210) (*price includes 1-6-1 (Operating Data Manual)) | 34 | Aug. 15/05 | TA 1 to 5 | 1 |
| 1-6-2 | Maintenance Manual (Series 1, 100 & 200) | 7 | Sep. 28/18 | 158, 161,162, 164 to 166, 168 to 179, 180 to 182. | 1 |
| 1-6-2W2 | Wiring Manual | Revised | Apr. 22/83 | W3 to W9 ⁷ | 1 |
| 1-6-4 | Illustrated Parts Catalogue (Series 100 & 200) | 4 | June 22/05 | 8 to 10, 14 to 20, 21 ⁸ , 22 ⁹ , 23 to 27 | 2 |
| 1-6-8 | Weight & Balance Handbook (Prepared for each aircraft on delivery) | Issue 6 | June 1968 | | 1 |
| 1-6-10 | Vendors Warranties Manual (Series 100, 200 & 300) | Initial Issue | N/A | | 1 |
| 1-6-7-D1 | Area Diagram (D1) including: | | | | 5 Posters |
| | 1-6-7(D2) – Access and Inspection Diagram | | | | |
| | 1-6-7(D3) – Lubrication Diagram (Updated May 2/14) | | | | |
| | 1-6-7(D4) – Servicing Diagram | | | | |
| | 1-6-7(D5) – Torque Values Diagram | | | | |
| | | | Jan. 31/06 | | |

⁷ TR W9 supersedes TR W6

⁸ TR-21 supersedes TR-16.

⁹ TR-22 supersedes TR-17.

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-6 TWIN OTTER (Series 300) | | | | | |
|--------------------------------------|--|-----------------|---------------------------|---|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-63-1 | Operating Data Manual *OBSOLETE – no longer available* SUPERSEDED by 1-63-POH | 7 (Erratum) | Nov. 16/05 (May 24/07) | | 1 |
| 1-63-1A-DOT | Airplane Flight Manual *OBSOLETE – no longer available* SUPERSEDED by 1-63-POH | 52 | June 30 /05 | | 1 |
| 1-63-1A-ARB | Airplane Flight Manual (Series 310) *OBSOLETE – no longer available - SUPERSEDED by 1-63-POH* | 38 | Jan.05 /06 | | 1 |
| 1-63-POH | Pilot Operating Handbook & Aircraft Flight Manual (Includes PSM1-63-1A) | 53 | Sept 10/10 | TA-01 to TA-12, & TR-01 to TR-03, TR-04 | 1 |
| 1-63-1A-SUPP | Supplement 37 Supplemental Performance Data (Flight Manual) | 3 | June 10/13 | | 1 |
| 1-63-2 | Maintenance Manual | 21 | Sep. 28/18 | 07-3, 12-17 to 12-19, 20-14, 20-15, 24-28, 27-22 to 27-26, 28-20, 29-5 to 29-7, 32-17, 32-18, 71-18, 76-6, 91-2, 11-8, 12-20, 52-1, 53-2, 53-3, 53-4 | 2 |
| 1-63S-2 | Maintenance Manual (Short Nose) | 21 | Sep. 28/18 | 7-3, 12-13 to 12-15, 20-4, 20-5, 24-8, 27-22 to 27-26, 28-19, 29-5 to 29-7, 32-15, 32-16, 71-2, 76-5, 91-3 | 2 |
| 1-63-2W | Wiring Manual | 14 | Oct.13/05 | W11 to W16, W18, W19, W21 to W24, W25 ¹⁰ , W26 ¹¹ , W27 | 1 |
| 1-63-4 | Illustrated Parts Catalogue | 25 | Apr. 30/19 | 27-1 to 27-3, 28-1, 28-2, 76-4, 76-5, 76-6 ¹² , 11-1, 33-1, 34-1, 34-2, 52-1 to 52-3, 53-1 to 53-5, 55-1 | 4 |
| 1-63-8(231) | Weight & Balance Handbook (S/N 231 to S/N 290) | 7 | Feb. 1969 | | 1 |
| 1-63-8(291) | Weight & Balance Handbook (S/N 291 & Sub.) | 8 | Aug. 1969 | | 1 |
| 1-63-8(303) | Weight & Balance Handbook (S/N 303 to 310 & 382) | 9 | Sep. 1986 | | 1 |
| 1-63-8(311) | Weight & Balance Handbook (S/N 311 & Sub.) | 10 | Mar. 1971 | | 1 |

¹⁰ TR W25 supersedes TR W23

¹¹ TR W26 supersedes TR W15

¹² TR76-6 supersedes TR 76-4.

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-6 TWIN OTTER (Series 300) | | | | | |
|--------------------------------------|--|-----------------|----------------------|--|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-63-8(331) | Weight & Balance Handbook (S/N 331 & Sub.) | 11 | Nov. 1972 | | 1 |
| 1-63-8(411) | Weight & Balance Handbook (S/N 411 & Sub.) | 12 | Nov. 1973 | | 1 |
| 1-63-8(541) | Weight & Balance Handbook (S/N 541 & Sub.) | 14 | Feb. 1978 | | 1 |
| 1-63-8(811) | Weight & Balance Handbook (S/N 811 & Sub.) | 16 | Dec. 1983 | | 1 |
| 1-6-10 | Vendors Warranties Manual (Series 100, 200 & 300) | Initial Issue | N/A | | 1 |
| 1-6-7-D1 | Area Diagram (D1) including: | | Jan. 31/06 | | 5 posters |
| | 1-6-7(D2) - Access and Inspection Diagram | | | | |
| | 1-6-7(D3) - Lubrication Diagram (Updated May 2/14) | | | | |
| | 1-6-7(D4) – Servicing Diagram | | | | |
| | 1-6-7(D5) – Torque Values Diagram | | | | |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-6 TWIN OTTER (Series 400) | | | | | |
|-------------------------------|---|----------|---------------|---|----------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-64-2 | Maintenance Manual | 8 | Sep. 28/18 | 07-2, 11-9,12-18 to 12-20, 20-13, 20-14, 24-17 to 24-19, 25-19, 27-33 to 27-37, 28-16, 28-17, 29-4 to 29-6, 31-37, 31-38, 32-19, 33-3, 33-4, 61-1, 71-6, 76-1, 76-3, 91-5 | 2 |
| 1-64-2W | Wiring Diagrams Manual | 3 | Nov. 30/18 | TREL-26, TR 20-8, 28-2 | 2 |
| 1-64-4 | Illustrated Parts Catalogue | 7 | Apr. 30/19 | 27-1 to 27-7, 28-1 to 28-3, 55-1, 76-4, 76-5, 76-6 ¹³ | 2 |
| 1-64-POH | Pilot Operating Handbook & Aircraft Flight Manual (Includes PSM1-64-1A) | 3 | Feb. 08/17 | TAs 26 to 33, 35, 36, 38 to 40, TA-42 ¹⁴ TRs 28 to 30, 34 to 36, 39, 40 | 2 |
| 1-64-QRH | Quick Reference Handbook | Issue 3 | Mar. 07/19 | | 1 |
| 1-64-1A-SUPP | Supplement 37 Supplemental Performance Data (Flight Manual) | Issue 3 | May 30/14 | | 1 |
| 1-64-8 | Weight & Balance Handbook – Imperial & Metric | Issue 8 | May 24/19 | | 1 |
| 1-64-8 (M) | Metric Weight & Balance | Issue 7 | May 24/19 | | 1 |
| 1-64-EPC | Emergency Procedure Cards – English Only | cards | | | cards |
| 1-6-13 | Airworthiness Limitations – Avionics (S/N 845 & Sub.) | 4 | Sep. 19/18 | | 1 |
| EASA-OSD-VAL-MMEL | EASA Master Minimum Equipment List | 1 | Dec. 20/18 | | 1 |
| 1-64-7-D1 | Area Diagram (D1) including: | | Mar. 10/11 | | 5 posters |
| | 1-64-7(D2) – Access and Inspection Diagram | | | | |
| | 1-64-7 (D3) – Lubrication Diagram (Updated May 2/14) | | | | |
| | 1-64-7 (D6) – Servicing | | | | |
| | 1-64-7 (D7) – Torque Values Diagram | | | | |

¹³ TR76-6 supersedes TR 76-4.

¹⁴ **TA-41 is superseded by TA-42.

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-5 Product Support Manuals (PSM)

| DHC-5 BUFFALO | | | | | |
|----------------------|---|-----------------|----------------------|---|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-5-1 | Airplane Operations Data | Revised | Mar. 01/78 | 42 to 52 | 1 |
| 1-5-2 | Maintenance Manual | Revised | Apr. 15/83 | 12-8 to 12-11, 20-1, 27-13 to 16, 29-6, 32-18 to 32-24, 32-26, 34-1, 34-2, 52-1, 53-1, 56-1, 61-1, 72-3, 76-1 | 5 |
| 1-5-2T | Tools & Equipment Manual | 3 | Nov. 20/81 | | 1 |
| 1-5-2W | Wiring Manual | 13 | Apr. 15/83 | 1 | 1 |
| 1-5-3 | Structural Repair Manual | 5 | Jan. 26/82 | 55-2, 55-3 | 1 |
| 1-5-4 | Illustrated Parts Catalogue | 7 | Sep. 07/89 | | 5 |
| 1-5-7 (PRE 108) | Inspection Requirements Manual (A/C 1 Thru 107) | 7 | Apr. 29/83 | 18 to 20, 22 to 24 | 1 |
| 1-5-7 | Inspection Requirements Manual (A/C 108 & Sub.) | 8 | Jan. 10/02 | 22, 23 | 1 |
| 1-5-8 | Weight & Balance Manual | 2 | Jan. 01/85 | | 1 |
| 1-5-10 | Power Plant Build-Up Manual | Initial Issue | May 21/82 | | 1 |
| 1-5-12 | Modifications & Options Manual | 4 | Oct. 31/11 | | 1 |
| 1-5A-1A | Airplane Flight Manual (CIVIL) | 4 | Mar. 31/86 | | 1 |
| 1-5A-7 | Inspection Requirements Manual (CIVIL) | 3 | Jan. 10/02 | 19 to 23 | 1 |
| 1-5A-8 | Weight and Balance Manual | | | | 1 |
| 1-5A/E-MMEL | Master Minimum Equipment List (Civil and Transporter) | Initial Issue | Apr. 25/83 | | 1 |
| 1-5D-1 | Aircraft Operating Data (S/N 60 to 107) | 6 | Sep. 15/82 | 31 to 34 | 1 |
| 1-5D/E-1 | Aircraft Operating Data (S/N 108 & Subs) | Supp. 7 | Jan. 27/82 | | 1 |
| 1-5D(108)-1 | Aircraft Operating Data (S/N 108 & SUBS) | 1 | Dec. 01/83 | 13 to 15 | 1 |
| 1-5D-6 | Component Maintenance Manual | 4 | Oct. 01/85 | 27-2, 32-1, 32-2 | 6 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

| DHC-5 BUFFALO | | | | | |
|----------------------|--|-----------------|----------------------|--|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-5D(108)-7 | Inspection Requirements Manual (S/N 108 & SUBS) | 2 | Jan. 10/02 | 11, 12, 15, 16 | 1 |
| 1-5D-8 | Weight & Balance Manual | Issue 3 | Jan. 1985 | | 1 |
| 1-5D-8A | Cargo Loading Manual | Initial Issue | Dec.14/81 | | 1 |
| 1-5D/E-2 | Maintenance Manual | 5 | Apr. 15/83 | 12-2, 12-3, 20-1, 27-3 to 27-7, 32-1 to 32-7, 32-9, 52-1, 53-1, 56-1, 61-1, 72-1, 76-1, 91-1 | 4 |
| 1-5D/E-2-CCV | Maintenance Manual (Volume 5) | Customized | Mar. 14/86 | | 1 |
| 1-5D/E-2-ARE | Maintenance Manual (Volume 5) (Arab Republic of Egypt) | Customized | Jan. 15/82 | | 1 |
| 1-5D/E-2W | Wiring Diagrams Manual | 2 | Apr. 15/83 | | 2 |
| 1-5E-1A | Airplane Flight Manual | 3 | Mar. 03/83 | | 1 |
| 1-5E-7 | Inspection Requirements Manual | Initial Issue | Dec. 19/80 | | 1 |
| 1-5-SB | Service Bulletins | 2 | July 08/04 | | 2 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | **Fax:** 403.295.8888 | **Email:** csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-4 Product Support Manuals (PSM)

| DHC-4 CARIBOU | | | | | |
|----------------------|-----------------------------|-----------------|----------------------|--|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-4-1 | Aircraft Operating Data | 2 | July 15/69 | 1 | 1 |
| 1-4-1A | Flight Manual | 6 | Jan. 04/71 | | 1 |
| 1-4-1B | Aircraft Loading Handbook | 1 | July 15/69 | | 1 |
| 1-4-2 | Maintenance Manual | 6 | Feb. 01/72 | 16 to 18, 4-19 to 4-22 | 1 |
| 1-4-3 | Repair Manual | 1 | June 06/69 | 1 to 8 | 1 |
| 1-4-4 | Illustrated Parts Catalogue | 4 | Sep. 01/72 | 1 to 8, 10 to 14 | 2 |
| 1-4-5 | Overhaul Manual | 4 | Feb. 02/72 | 3 | 1 |
| 1-4A-8 | Weight & Balance Handbook | | Jan. 01/59 | | 1 |
| 1-4-SB | Service Bulletins | 4 | Oct. 31/86 | | 2 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-3 Product Support Manuals (PSM)

| DHC-3 OTTER | | | | | |
|--------------------|--|-----------------|----------------------|--|-----------------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-3-1 | Airplane Flight Manual | 14 | Mar. 01/66 | | 1 |
| 1-3-2 | Maintenance Manual | 5 | July 23/18 | 23 | 1 |
| 1-3-3 | Structural Repair Manual | 1 | Aug. 01/63 | 1, 1-1, 2 | 1 |
| 1-3-4 | Illustrated Parts Catalogue | 3 | Dec. 18/19 | | 1 |
| 1-3-5 | Supplemental Inspection & Corrosion Control Manual | IR | Dec. 21/17 | 2-1 | 1 |
| 1-3-MOD | Modification Index | 3 | Apr. 11/19 | | 1 |
| 1-3-SB | Service Bulletins | 8 | Jan. 28/21 | | 1 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-2 Product Support Manuals (PSM)

| DHC-2 BEAVER | | | | | |
|--------------------------|--|----------|---------------|------------------------------------|----------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-2-1 | Airplane Flight Manual | 11 | July 08/02 | | 1 |
| 1-2-2 | Maintenance Manual | 4 | Mar. 28/18 | 2-43, 2-44, 2-46, 2-47, 2-49, 2-50 | 1 |
| 1-2-3 | Repair Manual | 3 | Apr. 30/03 | 6, 8 | 1 |
| 1-2-4 | Illustrated Parts Catalogue | 3 | Dec. 22/17 | 1 | 1 |
| 1-2-5 | Supplemental Inspection & Corrosion Control Manual | 1 | Jan. 10/19 | 1 | 1 |
| 1-2-8 | Weight & Balance Manual | | | | 1 |
| 1-2-MOD | Modification Index | 1 | Feb. 15/12 | | 1 |
| 1-2-SB/EB/TNS (Index) | Service Bulletins Engineering Bulletins Technical News Sheets (Turbo Beaver items not included) | M | Jan. 28/21 | | 1 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | Fax: 403.295.8888 | Email: csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

DHC-2 Product Support Manuals (PSM)

| DHC-2T TURBO BEAVER | | | | | |
|-----------------------|--|----------|---------------|------------------------------------|----------------|
| PSM Number | Description / Title | Revision | Revision Date | Outstanding Temporary Revisions | No. of Volumes |
| 1-2T-1 | Aircraft Operating Data | Original | Dec. 01/66 | | 1 |
| 1-2T-1A | Airplane Flight Manual | 14 | Jan. 20/78 | | 1 |
| 1-2-2 | Maintenance Manual | 4 | Mar. 28/18 | 2-43, 2-44, 2-46, 2-47, 2-49, 2-50 | 1 |
| 1-2T-2 | Supplementary Maintenance Manual (Sold with PSM1-2-2 Maintenance Manual) | 4 | Mar. 28/18 | 2T-19 to 2T-22 | 1 |
| 1-2T-4 | Illustrated Parts Catalogue (IPC) | 1 | Dec. 22/17 | TR-1 and TR-2 | 1 |
| 1-2-4 | Illustrated Parts Catalogue (IPC) | 3 | Dec. 22/17 | 1 | 1 |
| 1-2-5 | Supplemental Inspection & Corrosion Control Manual | 1 | Jan. 10/19 | 1 | 1 |
| 1-2T-8 | Weight & Balance Handbook | | | | |
| 1-2T-SB (Index) | Service Bulletins | K | Jan. 28/21 | | 1 |
| 1-2-SB/EB/TNS (Index) | Service Bulletins Engineering Bulletins Technical News Sheets (Turbo Beaver items not included) | M | Jan. 28/21 | | 1 |

Manual Status List – DHC-2 to DHC-7

Contact us for all Revision and Subscription inquiries:

Tel: 1.587.430.0572 | **Fax:** 403.295.8888 | **Email:** csps-tp@vikingair.com

CURRENT AS OF: December 1, 2022
(Yellow highlight indicates a change since last issue)

THIS PAGE INTENTIONALLY LEFT BLANK